

# INSTALLATION INSTRUCTIONS



*Patent Pending*

## **Step 1:**

Snap chalk line and cut a slot 2" wide total along ridge (or 1" on each side of ridge beam). Allow for a closed area of sheathing 18" at both ends of ridge.

## **Step 2:**

Center vent over slot at one end with flat side facing up. Fasten with two nails (minimum nail 1 3/4"). If using nail gun, recommended compressor pressure is between 90 and 100 psi. Roll out along entire ridge covering uncut 18" sheathing area on both ends, pull out slack, and fasten with two nails at opposite end.

## **Step 3:**

Center ridge cap shingles over vent and install with minimum 1 3/4" nails. Assure nails penetrate into sheathing 3/4" or completely through sheathing.

*2 inch slot required at ridge.  
Must be installed with a minimum nail size of 1 3/4 inch.  
Can be installed with a nail gun.*

**BENJAMIN  
OBDYKE**  
residential roof & wall products

**Benjamin Obdyke Incorporated**

**400 Babylon Road, Suite A**

**Horsham, PA 19044**

**800.346.7655 • [www.benjaminobdyke.com](http://www.benjaminobdyke.com)**